

Double-click ==> Autorun Pro Enterprise.exe

Follow these steps to install the Juntek/Koolertron Generator USB program:

Select your preferred language; "English" or "Chinese"

Step 1 Click "Install USB Driver"

Click "Yes" and the driver will install.

When finished close the DriverSetup(X64) window.

Step 2 Click "Install NI-VISA"

Click "Yes"

Click "Next >>"

Click "Next >>" again.

Under Run Time Support, there are 10 support packages.

You only need the "USB" Run Time Support.

Click the pull-down menu on the other 9 and set to "Do not install this feature"

An "X" appears next to the unselected support packages.

Make sure the "USB" support package is set to "Leave this feature installed locally"

Click "I accept the ... License Agreements"

Click "Next >>"

PLEASE UNCHECK the box for "Search for messages and updates ..."

Click "Next >>" again.

The NI-VISA program will install.

Click "Finish"

Close the "Autorun Pro Enterprise.exe" program

Left-click the "HOUSE" icon in the upper-right corner of the Language box.

Left-click the "RED" square icon in the upper-right corner of the "DDS Signal generator" box.

END.